

Active Length of Sedimentation Tank

$$L_{active} = L_{original} - L_{standing} \cdot \cos(\alpha)$$