## **ANSYS AIM Permanent Magnetic Circuit with Air Gap - Physics Setup**


Authors: Joshua Wallace & Steve Scampoli, ANSYS Inc.

**Problem Specification** 

- 1. Pre-Analysis & Start-Up
- 2. Geometry
- 3. Physics Setup
- 4. Numerical Solution/Results


## **Physics Setup**

In the Workflow, press the Physics button. Right click on the enclosure and select Hide Body.



## **Specify Material**

Next to **Material Assignments**, press the **Add** drop down menu **Material Assignment** > Search for **Cast Iron (Material Samples)** and select it. Make sure you change the **Isotropic relative permeability** to 1(10)^5. Next, click on the **Body Selection** tool in top right corner and select the three beams and click **Add**.



Next, a magnetic material will be created. Instead of searching for cast iron, search "Mag" and click on Create Mag. Set the Default State to Solid. To create a material property, select Add and choose the following material properties. Input 625000 S m^-1 for Isotropic Electrical Conductivity. Input 5.305 for Isotropic Relative Permeability. Input 150000 A m^-1 for the Magnetic Coercivity. (You can use "Type to Search" to find the Magnetic Coercivity property.) Select Cartesian magnetization direction, then input 3/2 for the X direction (you can enter the expression sqrt(3)/2 to define the x direction) and 1/2 for the Y direction.

