

CorelDRAW

Overview

CorelDRAW is used to control the [Versalaser](#).

Invoking

Start CorelDRAW via the [RemoteApp](#) icon on the CNF Windows workstations.

CorelDraw will not work properly when accessed from Linux – if still necessary, CNF Computing can help you to run CorelDraw on a remote Windows desktop via Linux. For remote access, we recommend subscribing to the [CNF Virtual CAD Room service](#).

Templates

Four templates are available to assist with using CorelDRAW and the Versalaser. The templates are located on the remote machine in a toplevel folder named "CNF" on the C: drive: [c:\cnf\](#).

File Formats

Please see [this document](#) on Corel's website for a list of supported file formats in CorelDraw X6.