

# FLEXUS WinFLX

The [Flexus Film Stress Measurement](#) software may be run in an offline mode for analyzing and plotting your collected data.

## Invoking

The software is run via [RemoteApp](#) .

On Windows, use the FLEXUS icon on the desktop to remotely run the software.

On any of the CNF Thin computers, type in:

```
flexus
```