FLUENT - Supersonic Flow Over a Wedge- Step 2

Problem Specification

- 1. Pre-Analysis & Start-up
- 2. Geometry
- 3. Mesh
- 4. Setup (Physics)
- 5. Solution
- 6. Results
- 7. Verification & Validation

Step 2: Mesh Geometry in GAMBIT

Mesh Faces

We will mesh each of the 2 faces separately to get our final mesh. Before we mesh a face, we need to define the point of distribution for each of the edges that form the face.

We will use the default setting for meshing of the edge.

Select the edge AB. The edge will change color and an arrow will appear on the edge. This indicates that you are ready to mesh this edge. Select interval size under *Spacing*. Enter 0.04 for interval size.

Next we will mesh the edge BC. Select the edge BC and enter 0.04 for interval size.


Do the same for edge CD and CF.

Now that the appropriate edge meshes have been specified, mesh the face face1:

Operation Toolpad > Mesh Command Button > Face Command Button > Mesh Faces

Select the face1. The face will change color. You can use the defaults of Quad (i.e. quadrilaterals) and Map. Click Apply.


The meshed face should look as follows:



Higher Resolution Image

Next mesh face face2 in a similar fashion.

The resultant mesh should look as follows:



Higher Resolution Image

Note that for each mesh face, we only define 2 mesh edges. Gambit will automatically define the other two mesh edge for face mesh creation. Manual mesh of all edges can be done if more control of the mesh is required. Please refer to the index of the GAMBIT User Guide and look under *Edge>Meshing* for explanation on other type of meshing parameters.

Go to Step 3: Mesh

See and rate the complete Learning Module

Go to all FLUENT Learning Modules