ANSYS - Bike Crank (Part 2)

Author: Sebastien Lachance-Barrett, Cornell University

Problem Specification

- 1. Pre-Analysis & Start-Up
- 2. Geometry
- 3. Mesh
- 4. Physics Setup
- 5. Numerical Solution
- 6. Numerical Results
- 7. Verification & Validation

Exercises Comments

Bike Crank: Part 2

Created using ANSYS 14.5



This tutorial has videos. If you are in a computer lab, make sure to have head phones.


Learning Goals

In this tutorial, you will learn to:

- Determine the strain values that would be measured by a strain rosette mounted on the bike crank.
- Verify the finite-element results from ANSYS by comparing it with hand calculations using Euler-Bernoulli beam theory.

Problem Specification

Consider adding a strain rosette to the ANSYS bike crank model from the previous bike crank tutorial to predict the strain that would be measured by a rosette mounted on the crank model. The rosette is placed along the top edge on the front face of the crank, midway between the support hole and the loaded hole as shown below.




The location of the gauge centers with respect to a coordinate system centered at the front face of the support hole is as follows:

Left Gauge: (3.244 in, 0.219 in) **Middle Gauge:** (3.346 in, 0.219 in)

Right Gauge: (3.448 in, 0.219 in)

The rosette dimensions are shown in the figure below.



Rosette Height (RH)	0.268"	Gage Length (GL)	0.083"
Rosette Width (RW)	0.413"	Gage Width (GW)	0.063"

Determine the strain value that would be measured by each gauge on the rosette. Each gauge measures the extensional strain along its length (the longer dimension).

Go to Step 1: Pre-Analysis & Start-Up

Go to all ANSYS Learning Modules