

FOOD SAFETY LAB / MILK QUALITY IMPROVEMENT PROGRAM

Standard Operating Procedure

Title: actA PCR Protocol

Revision: 00

Revision Date: n/a

Effective Date: 2019-10-11

Authors: Emily Wright, Jordan Skeens, Rachel

Miller

SOP #:

Approved by:

acta PCR ASSAY TO DIFFERENTIATE LISTERIA MONOCYTOGENES FSL R3-0001 CONTROL STRAIN FROM WILD-TYPE STRAINS

FILE NAME: actA PCR Protocol_10112019.doc

FSL/MQIP @ CORNELL UNIVERSITY

Revision 00

Revised 10/11/2019

TABLE OF CONTENTS

- 1. INTRODUCTION
 - Purpose
 - Scope
 - Definitions
 - Safety
- 2. MATERIALS
- 3. PROCEDURE
- 4. TROUBLESHOOTING
- 5. REFERENCES

Revised 10/11/2019

Effective 00/00/0000

Revision 00

SECTION 1 INTRODUCTION

1.1 **Purpose**

A standard actA PCR method that allows differentiation of the L. monocytogenes control strain FSL R3-0001 from wild-type L. monocytogenes strains. FSL R3-0001 is currently used as a genetically modified control strain by Silliker laboratories and this procedure will allow the user to determine whether L. monocytogenes isolates from test samples represent wild-type isolates or contamination with FSL R3-0001.

This SOP is derived from an earlier protocol titled "actA PCR ASSAY TO DIFFERENTIATE LISTERIA MONOCYTOGENES FSL R3-001 CONTROL STRAIN FROM WILDTYPE STRAINS" authored by Emily Wright. The original protocol can be found archived on the Food Safety Wiki.

1.2 Scope

This SOP applies to the Food Safety Lab, including the Laboratory for Molecular Typing.

1.3 **Definitions**

BP: base pair

dNTPs: deoxyribonucleotide monomers, which are the building blocks of DNA. There are four dNTPs: cytosine, adenine, guanine and thymine

GoTaq Green: A PCR kit containing thermostable Taq polymerase, MgCl₂, and a PCR buffer which contains a green loading dye. This loading dye does not interfere with the PCR and saves the step of loading dye incorporation prior to running gel electrophoresis.

PCR: polymerase chain reaction, used to amplify a specific region within a DNA sequence

1.4 Safety

Appropriate protective measures need to be taken when working with L. monocytogenes.

All waste from these experiments needs to be treated as BSL-2 waste.

SECTION 2 MATERIALS

Revised 10/11/2019

Revision 00 Effective 00/00/0000

- Sterile water Room 358B and Room 350A
- Sterile 0.2 mL tubes Room 358B and Room 350A
- mpl-xbaF (forward) Primer, 12.5 μM (5' GCT CTA GAT CAA CAA GCA GCG AAA GATT - 3') - Room 352C, chest freezer
- actA MassR (reverse) Primer, 12.5 μM (5' TTT ATG TGG TAA TTT GCT GTC 3') - Room 352C, chest freezer
- GoTaq Flexi Polymerase Room 352, "Dumb" freezer
- GoTag Green 5x PCR Buffer Room 352, "Dumb" freezer
- dNTP solution consisting of 10 mM each dATP, dGTP, dCTP, dTTP dNTP stocks in Room 352, "Dumber" freezer, in covered cryoblock
- MgCl₂, 25 mM Room 352, "Dumb" freezer
- Vortex Mixer Room 358B
- Miniature Centrifuge Room 358B
- Thermocycler Room 356
- Micropipette and sterile filter tips
- Crushed Ice

High Throughput Reactions (96-well plate)

- Sterile reservoir basin Room 358B
- Sterile 96-well plates Room 358B
- Multi-channel pipette
- Sterile water Room 358B and Room 350A
- mpl-xbaF (forward) Primer, 12.5 μM (5' GCT CTA GAT CAA CAA GCA GCG AAA GATT - 3') - Room 352C, chest freezer
- actA MassR (reverse) Primer, 12.5 μM (5' TTT ATG TGG TAA TTT GCT GTC 3') - Room 352C, chest freezer
- GoTaq Flexi Polymerase Room 352, "Dumb" freezer
- GoTaq Green 5x PCR Buffer Room 352, "Dumb" freezer
- dNTP solution consisting of 10 mM each dATP, dGTP, dCTP, dTTP dNTP stocks in Room 352, "Dumber" freezer, in covered cryoblock
- MgCl₂, 25 mM Room 352, "Dumb" freezer
- Vortex Mixer Room 358B
- Miniature Centrifuge Room 358B
- Thermocycler Room 356
- Adhesive aluminum foil lids Room 358B
- Micropipette and sterile filter tips
- Crushed Ice

SECTION 3 PROCEDURES

3.1 Lysate Preparation

Refer to the "Preparing DNA Lysates" SOP on the Food Safety Lab wiki.

FSL/MQIP @ CORNELL UNIVERSITY

Effective 00/00/0000

Revision 00

1X (50μL rxn)

Revised 10/11/2019

3.2 PCR Amplification

- 3.2.1 Working in Room 358B, prepare a master mix of the components listed in Table 1 by pipetting each component into a sterile 1.5 mL microcentrifuge tube (and a 0.2ml PCR tube for the Taq Mix if using GoTaq).
 - 3.2.1.1 Pipette up and down to mix after each addition and to ensure that no reagent clings to the pipette tip.
 - 3.2.1.2 Store all master mix components and the prepared master mix on crushed ice.
 - 3.2.1.3 Vortex and centrifuge down the contents of all reagent containers before opening (<u>DO NOT</u> vortex the Taq or any solutions containing Taq, flick the tube to mix these solutions)
 - 3.2.1.4 Calculate master mix volumes required to include positive and negative controls and 1-2 additional reactions to compensate for pipetting errors.

Table 1: actA PCR Master Mix

|--|

Master Mix:	1X (50μL rxn)
• dH ₂ 0	20.5 μL
• 5X PCR buffer	8.0 μL
• MgCl ₂ (25mM)	$3.0~\mu L$
• dNTPs (10mM)	2.5 μL
• mpl-xbaF (12.5μM)	$2.0~\mu L$
• actA MassR (12.5μM)	$2.0~\mu L$
	38 μL per tube

Taq Mix:

	10 μL per tube
• Taq polymerase (GoTaq)	0.4 μL
• 5X PCR buffer	2.0 μL
• dH ₂ 0	7.6 µL
-	·

Revision 00



3.2.3 Manual Hot Start

- 3.2.3.1 Dispense 38 µL of prepared master mix (but not the Taq Mix) into each well (one well per lysate to be amplified) in a 96-well PCR plate or into individual 0.2 mL PCR tubes. Cover the plate loosely or cover the tubes and hold on ice.
- 3.2.3.2 Remove the plate or tubes containing the master mix from room 358B to a lab bench.
- 3.2.3.3 Briefly spin down the previously-prepared lysates in a centrifuge, then add 2μL of lysate to its corresponding PCR well or tube. Pipette up and down to
- 3.2.3.4 Briefly centrifuge the PCR plate or tubes to concentrate reagents at the bottom of the tube.
- 3.2.3.5 Perform the reaction using the following set of cycling conditions:

Tr 11	DOD	C 1'.'
Louchdown	PCK	Conditions:

94°C	3 min	
94°C	1 min	
53°C	1 min	40 cycles
72°C	2 min	
72°C	5 min	
4°C	Hold	

- 3.2.3.6 Place the rack in the PCR machine, with a compression pad, and begin the cycle. Once the sample temperature reaches 80°C, pause the program and wait for the temperature to stabilize.
- 3.2.3.7 Add 10µL of the Taq Mix to each PCR tube. Ensure all the tube caps are tightly closed, then close the thermocycler lid and resume the program.
- Promptly remove the reactions from the thermocycler when complete. PCR product can be stored at 4°C for up to 1 week or at -20°C for up to 6 months.

3.3 Gel Electrophoresis Confirmation of Amplification

Refer to the "Gel Electrophoresis of PCR Product" SOP on the Food Safety Lab wiki.

3.4 ExoSAP Purification and Sequencing Submission

Refer to the "PCR Product Purification and Sanger Sequencing Submission" SOP on the Food Safety Lab wiki.

Revised 10/11/2019

Effective 00/00/0000

Revision 00

3.5 Sequence Analysis

Refer to the "Automated Sequence Editing" SOP on the Food Safety Lab wiki.

SECTION 4 TROUBLESHOOTING

4.1 Issues with MgCl₂

- 4.1.1 MgCl₂ forms a concentration gradient when frozen and needs to be vortexed prior to
- 4.1.2 Every PCR reaction has an optimal MgCl₂ concentration range, usually between 1-4 mM. Since Mg⁺² forms complexes with dNTPs and acts as a cofactor for polymerase you may need to try several conditions to optimize your concentration.

4.2 **Too Much Enzyme**

4.2.1 Excess enzyme in your PCR can lead to smearing of PCR products.

4.3 Wrong Primer Concentration

- 4.3.1 If you have too little primer you won't see any product.
- 4.3.2 Too much primer may result in primer dimerization, which may reduce amplification.

4.4 Wrong PCR Program

4.4.1 Check your program while it's cycling to make sure it is the right program.

4.5 Excess or Insufficient Template

- 4.5.1 Too much template can inhibit PCR by binding all of the primers. If the lysate appears very turbid, dilute the template 1:10 or 1:100 and then use 1 μ L of the diluted template for the PCR.
- 4.5.2 Too little template and amplification may be undetectable. Make sure you correctly prepared your dirty lysate and that you took a sufficiently large sample from your culture.

4.6 Too Much dNTP or Degraded dNTP

4.6.1 Excess dNTP inhibits PCR. Between 40-200 μM is optimal. dNTPs are sensitive to repeated freeze-thaw cycles. Make small aliquots when you get a fresh batch and turn over your stock frequently.

FSL/MQIP @ CORNELL UNIVERSITY

Effective 00/00/0000 Revision 00 Revised 10/11/2019

SECTION 5 REFERENCES

Frame, Peter. (2010). Ten Things That Can Kill Your PCR. Bio-Synthesis. www.biosyn.com.