

AIM Plate with Hole - Mesh

Author(s): Sebastian Vecchi, ANSYS Inc.

[Problem Specification](#)

[1. Pre-Analysis & Start-Up](#)

[2. Geometry](#)

[3. Mesh](#)

[4. Physics Setup](#)

[5. Results](#)

[6. Verification & Validation](#)

Mesh

[Close the modeling window, then initiate the meshing process by clicking on Mesh in the workflow.](#)

Set Mesh Size

Using the **Mesh resolution** slider, we can edit how precise our mesh is for our calculations. [Move the slider all the way to the right](#), to give us the most accurate data. [Under Global Sizing, change the Size function method to Curvature](#). The Curvature option allows the mesh to become more refined closer to the circle.

Generate Mesh

[Click Generate Mesh under Output or at the top of the screen by the status window for Mesh](#). AIM should detect you are ready to generate the mesh and highlight the buttons in blue.

[Go to Step 4: Physics Set-Up](#)

[Go to all ANSYS AIM Learning Modules](#)