

# FLUENT - Flow Past a Cylinder - Step 3

[Problem Specification.](#)

1. [Create Geometry in GAMBIT.](#)

2. [Mesh Geometry in GAMBIT.](#)

3. **Specify Boundary Types in GAMBIT.**

4. [Set Up Problem in FLUENT.](#)

5. [Solve.](#)

6. [Analyze Results.](#)

7. [Change the Domain Size.](#)

8. [Unsteady Flow.](#)

[Problem Set.](#)

[Citations.](#)

## Specify Boundary Types in GAMBIT

### Define Boundary Types

#### Operation Toolpad > Zones Command Button > Specify Boundary Types

Select **Add**, fill in inlet for **Name**, VELOCITY\_INLET for **Type**, select EF and EL for Edges, then click **Apply**.

Similarly, define FG, GH, LK and KJ named wall as WALL Type.

Define BCD and BMD named cylinder as WALL Type.

Define HI and JI named outlet as PRESSURE\_OUTLET Type.

### Save Your Work

Main Menu > File > Save

### Export Mesh

Main Menu > File > Export > Mesh...

Save the file as cylinder.msh.

Go to [Step 4: Set Up Problem in FLUENT.](#)

[See and rate the complete learning module.](#)

Go to [all FLUENT Learning Modules](#)